

Goldfinger

Features:

- 2 Channel Tube Amplifier
- Choice of variable Boost or Pre FX loop
- Boost or Pre FX individually footswitchable for each channel
- Footswitch controllable Tube-buffered series or parallel Post FX-Loop
- Footswitch controllable spring reverb*
- α Ch.: Bass, Middle, Treble, Gain & Loudness controls, Pre & Post Bright switches
- Ω Ch.: Bass, Middle, Treble, Gain EQ, Gain & Loudness controls, 69/80 mode switch
- Full and Low output power switch
- Functions on footswitch: α/Ω ch. select, α boost/pre-fx, Ω boost/pre-fx, reverb, post-fx
- ½ Output Power Mode – 4 Step- from 45W to 9W


OPTIONS:

- Available as a Head or 1x12" open back combo*
- 45 watt 6V6 or 90 watt EL34 Power Amp Section
- Matching open 1x12 cabinet
- Matching open or closed 2x12 cabinet

* The Goldfinger 90 is not available as 1x12 combo

DIMENSIONS and WEIGHTS: Are subject to change anytime, Please measure *your* amp carefully if a Custom Case is being made. *Add ¾ inch for each, handle and rubber feet.*

GF45 Head:	9" H	25.50" W	10.25" D	42 pounds
GF90 Head:	9.75" H	25.50" W	10.25" D	47 pounds
GF45 1x12 Combo:	19.50" H	25.50" W	10.75" D	66 pounds
1x12 open Cabinet:	19.50" H	25.50" W	10.75" D	43 pounds
2x12 open Cabinet:	24.50" H	25.75" W	10.25" D	54 pounds



- | | | |
|--------------------------------|-----------------------------|----------------------|
| 1) power on/off switch | 30) pre boost gain | 60) V1 |
| 2) standby hi/low | 31) pre fx loop send | 61) V2 |
| 3) presence | 32) pre fx loop return | 62) V3 |
| 4) channel select | 33) footswitch connector | 63) V4 |
| 5) pre fx boost | 37) post fx on/off | 64) V5 |
| 6) α loudness | 38) post fx series/parallel | 65) V6 |
| 7) α gain | 39) post fx +4/-20db | 66) V7 |
| 8) 80 – 69 mode | 40) post fx send | 67) V8 |
| 9) Ω loudness | 41) post fx return | 68) V9 |
| 10) Ω gain eq | 42) post fx loop gain | 70) V6/7 bias adjust |
| 11) Ω gain | 44) dual speaker outs | 71) bias test point |
| 13) instrument input | 45) ohm selector for 44) | 72) V8/9 bias adjust |
| 14) Ω bass | 46) 16 ohm speaker out | |
| 15) Ω mid | 47) h.t. fuse | |
| 16) Ω treble | 48) 1/2 Pwr Switch | |
| 17) α bass | 49) power cable connector | |
| 18) α mid | 50) main fuse | |
| 19) α treble | | |
| 20) reverb | | |
| 21) post fx | | |
| 22) pilot lamp power indicator | | |
| 23) α post bright | | |
| 24) α pre bright | | |